

01	Box bottom plate
02	Box top plate
03	Box cylinder
04	Axis bearing support
05	Axis cover
06	Axis seal support
07	Central axis bearing support – bottom
08	Central axis cover
09	Central axis bearing support – top
10	Central axis seal support
11	Central pulley
12	
13	Motor support
14	Dust cover support
15	Axis
16	Central axis
17	Motor coupling
18	Tension roller
19	Tension roller axis-1
20	Tension roller axis-2
21	Tension block top plate
22	Tension block frame
23	
24	Tension block cover
25	Axis coupling
26	Driving disk – ring
27	Driving disk – coupling
28	Driving disk – base
29	Driving disk – stud ring
30A	Driving disk – central block 1
30B	Driving disk – central block 2
31	Dust cover
32	Machine frame
33	Handle gear base
34	
35	Wheel axis
36	Operation arm
50	Central axis pulley
51	Axis pulley
52	Motor
53	Machine wheel
61	Main belt
62	Top belt
B1	Bearing 6005
B2	Bearing 6004
B3	Bearing 6206
B4	Bearing 16015
G1	Gasket Ø90
G2	Gasket Ø90xØ55
G3	Gasket Ø150xØ90
G4	Gasket Ø85
G5	Gasket tension block
R1	Oil seal Ø55xØ40x8
R2	Oil seal Ø180xØ150x15
K1	Keyway 8x7
S1	Countersunk head screw M6x10
S2	Countersunk head screw M6x16
S3	Button head screw M6x16
S4	Countersunk head screw M8x25
S5	Countersunk head screw M6x25
S6	Socket cap screw M10x25
S7	Countersunk head screw M8x16
S8	Socket cap screw M4x8
S9	Socket cap screw M6x40
S10	Hexagon H.T. bolt M12x30
S11	Button head screw M8x12
AV1	Anti-vibration element 1
AV2	Anti-vibration element 2
AV3	Anti-vibration element 3