

01	Central axis bearing support – bottom
02	Axis bearing support
03	Axis seal support
04	Axis cover
05	Central axis cover
06	Central axis seal support
07	Central pulley
08	
09	Central axis bearing support – top
10	Central axis
11	Axis
12	Motor coupling
13	Motor support
14	
15	
16	Holding block
17	Dust cover support
18	Box bottom plate
19	Box top plate
20	Box cylinder
21	Dust cover
31	Axis coupling
32	Driving disk – ring
33	Driving disk – coupling
36	Silicon seal size 1
37	Silicon seal size 2
38	Central axis pulley
39	Axis pulley
40	Tension block top plate
41	Tension block spacer
42	Tension block bottom plate
43	Tension roller
44	Tension roller axis-1
45	Tension block cover
47	Tension roller axis-2
51	Driving disk – stud ring
52	Driving disk – base
53A	Driving disk – central block 1
53B	Driving disk – central block 2
54	Disk holding pin
61	Main belt
62	Top belt
63	Oil seal Ø52xØ25x10
64	Oil seal Ø62xØ45x8
B01	Bearing 6305
B02	Bearing 6207
B03	Bearing 6017
B06	Bearing 51124
G03	Gasket Ø110xØ52
G04	Gasket Ø110
G05	Gasket Ø120
G06	Gasket Ø200xØ116
K01	Keyway 8x7
S01	Countersunk head screw M8x16
S02	Countersunk head screw M8x30
S03	Button head screw M6x16
S04	Countersunk head screw M10x25
S05	Button head screw M8x12
S06	Socket cap screw M6x50
S07	Countersunk head screw M8x25
S08	Hexagon H.T. bolt M12x30
S09	Hexagon H.T. bolt M10x30
S10	Countersunk head screw M6x16
S11	Socket cap screw M4x8
S12	Anti-vibration nut M8
AV1	Anti-vibration element 1
AV2	Anti-vibration element 2
AV3	Anti-vibration element 3
AV4	Anti-vibration element 4
L01	Compress spring for disk holding pin